



1. Go to Start → Right Click on Computer → Go to Properties




2. Click on Advanced System Setting → Go to Hardware Tab → Device installation Setting → Select No, let me choose what to do → Then Select Never install driver software from windows update → Save Changes




3. Now go to Device Manager → Check for connected biometric Device

- If Biometric Device Shows **Secugen Fingureptint Device**




Go to Step 4 for installation

- If Biometric Device Shows **In Other Devices With Yellow mark** then install drivers




Go to Step 8


- If Biometric Device Shows **propriety drivers** Then skip the driver installation.




4. Right click & Click on Uninstall




5. Select the check mark Delete the drivers → Click on Ok Restart you Machine & reconnect Biometric device .



6. Open Device Manger again , Then go to Computer name & right click on computer name →Then click on scan for hardware changes



7. Now the SecuGen USB U20 biometric device will appears in Other devices



8. Driver Installation

Go to www.Secugenindia.com

- Click solutions Tab
- Go to Link 5) [SecuGen RD Services Click here](#)
- Then click on [SecuGen Pro20 Device Drivers](#)


Or

You can directly download the drivers from below link


http://www.secugenindia.com/rdservice/downloads/U20_Legacy_Driver_v127.zip

9. After Downloading the drivers extract the zip


- Then again go to Device Manager
- Right click on SecuGen USB U20
- Then click on Update Driver Software




10. Then Select → Browse my computer for driver software




11. Browse the path where you extracted the drivers



12. Click next → then select check mark → then click on install




13. Shows the below screen now the drivers are installed successfully.



❖ Now the installation of RD Service


- Go to <http://secugenindia.com/rdservice.html>
- Then scroll down till the updates
- Click on Secugen RD Service for Windows Production (Build No. 25).

Note : Build no version can be different Like 25 Or any updated version .



- Extract the zip & then install the setup
- Now go to Below path → C:\ Program Files\SecuGen\RDService OR
C:\ Program Files(X86)\SecuGen\RDService

➤ Now run the sgirdclient.exe



(It requires .Net v4) to check the RD service status

Or

➤ You can check form logs in the same folder *.log file (C:\SecuGen\RDService\)

- ✓ If RD Service status is READY then Please contact the application Team .
- ✓ If RD Service status is NOT Ready please check with support Team.

Please also go through below docs.

Reference

http://www.secugenindia.com/rdservice/downloads/SecuGen_RD_HLA.pdf

http://www.secugenindia.com/rdservice/downloads/SecuGen_RD_Network.pdf


http://www.secugenindia.com/rdservice/downloads/SecuGen_RD_FAQ.pdf

If you are facing the error “TimeStamp (ts) value is expired”


➔ Go to Control panel → Date & Time

➔ In Time Zone the Location should be **(UTC+05:30) Chennai, Kolkata, Mumbai, New Delhi**

If not you have to change it from change Time Zone Option



➔ Go to Internet Time Click on Change Settings In Server Select **“time.nist.gov”** Click on Update Now



➔ After Successfully Time Synchronised

➔ Restart Secugen RD Service In “Services.msc”

